# Pilot burner SDB and SCF 40





**GUANGZHOU SINON COMBUSTION** EQUIPMENT CO., LTD.

- © 020-84581309
- 020-84507159
- www.gzsinon.net

### **CHARACTERISTICS**

- SDB and SCE 40 are both pilot burners with forced air supply.
- SDB: premixed combustion with stable and strong flame. SCE 40: non-premixed combustion with no flareback
- SDB 1: 1~2kW, SDB 2: 2.5~4kW, SDB 4: 2~7kW, SCEM 40/SCEC 40: 5~20kW.
- Thanks to the removable mounting device, pilot burner SDB 1 and SDB 2 are convenient to operate and have flexible installation positions.
- Can only be used with non-preheated air.
- Fuel: LPG, natural gas, town gas and other clean fuel gas.

## **APPLICATIONS**

Low-capacity burners SDB and SCE 40 are mostly used as safe pilot burner of high-capacity burners due to their good flame stability and can also be used independently.



## **CONFIGURATION**

- The pilot burner SDB 1 and SDB 2 are composed of pre-mixer, electrode, and flame guide tube, while the SDB 4 is composed of burner housing, protective tube and flame guide tube.
- Both the gas and air inlet of pilot burner SDB have a pressure test nipple, which can be used for measuring the gas and air inlet pressure.
- The pilot burner SCE 40 is composed of air housing, gas system, electrodes, and burner tube. The SCEM 40 is used with metal burner tube, while the SCEC 40 is used with ceramic burner tube.
- The gas and air inlet of SCE 40 are both equipped with orifice plates and pressure test nipples for pressure measurement.
- The pilot burner SDB 1 and SDB 2 can only be used with singleelectrode ignition/detection. In addition to single-electrode ignition/detection, the double-electrode ignition/detection is also available for the pilot burner SDB 4 and SCE 40.


#### SDB 1/SDB 2:



SDB 4:



SCEM 40:





## **SPECIFICATION**

## Type table

#### SDB series

Туре					SDB	4	N	150/	100
Capacity*	1: 1~2kW		2: 2.5~4kW		4: 2~7kW				
Fuel	N: N	N: Natural gas			T: Town gas				
	T: To	own gas	M: Mixture gas (only for SDB 4						
Protective	tube	150	200	250	150+50n				
length (mm)**		130	200	230	130+3011				
Flame guide tube		100	150	200	150+50n				
length (mm)***		100 13	130	200	130+3011				

<sup>\*</sup>Capacity when using natural gas as fuel gas.

#### SCE 40 series

Туре				SCEM	40	L	N	200	/135
Combustion cham-	SCEM: Metal		SCEC: Ceramic						
ber material	SCLIVI. IVIE	ıaı	SCLC. CE	Tattiic					
Capacity	40: 20kW								
Flame shape	L: Long fla	me							
Flue	N: Natural gas		P: LPG		T: Tov	vn gas			
Burner tube length	100	150	200	100+50n					
/mm	100	130	200	100+3011					
Burner core length	35	85	135	35+50n					
/mm		0.5	155	3313011					

The pilot burner's capacity should be 2~5% of the main burner's capacity.


<sup>\*\*</sup>Only SDB 4 has protective tube, and the burner length of SDB 4 can be adjusted by changing the length of protective tube.


<sup>\*\*\*</sup>The length of flame guide tube of SDB 4 is fixed 100mm, and the shortest flame guide tube length of SDB 1 and SDB 2 is 150 mm.



## **Dimensions**


#### SDB 1/SDB 2






Туре	А	G	М	D	Hg	Ha	Н	L	W
SDB 1	$\operatorname{Rp}^{1}/_{2}$ "	$Rp^{1}/_{4}$ "	$^{\rm G}^{\rm 1}\!/_{\rm 2}$	16	37.5	93.5	17.5	40	40
SDB 2	$\operatorname{Rp}^{1}/_{2}$ "	$Rp^{1}/_{4}$ "	G 1	25	37.5	93.5	17.5	40	40

#### SDB 4




### SCEM 40



Unit: mm



#### SCEC 40



Unit: mm

### **INSTALLATION**

- The pilot burner is mostly installed on main burner. If the pilot burner needs to be installed separately, please consult us and choose a suitable location.
- It's recommended to install a gas filter on the main gas tube of pilot burner. Before the pipe is connected to the burner, it must be purged to prevent welding slag or other debris from entering the burner and affecting the normal operation of the burner.
- If a pipe welding is required after the connection between burner and pipeline, ensure that there is no welding slag or molten substance falls into the pipe or burner.

## **OPFRATION**

#### Attention

- Can only be used with non-preheated air.
- For SDB 1 and SDB 2: ensure that the temperature of the flame guide tube between the premixer and burner head of the burner does not exceed the gas ignition point, generally recommended not exceeding 500 °C. And the temperature of the flame guide tube of the downstream of the burner head must be lower than 1000 °C.



- For SDB 4: ensure that the temperature of the SDB 4's protection tube do not exceed the gas ignition point, generally recommended not exceeding 500 °C. And the temperature of SDB 4's flame guide tube must be lower than 1000 °C.
- In order to ensure the continuous and stable combustion of the pilot burner SDB 1 and SDB 2, the air pressure at the burner inlet should not less than 5kPa, and the gas pressure should be kept within the appropriate range, as shown in the figure on the right (the flue is natural gas).
- For SCE 40, the pressure difference of the air orifice plate should be maintained at about 35mbar, and the pressure difference of the gas orifice plate should be maintained at about 25mbar.
- Ensure that the air continues to enter the burner when the burner is closed to cool the burner

SDB 1: 36 sas pressure/mbar 24 Air pressure/mbar

42 Gas pressure/mbar 36 60 Air pressure/mbar

SDB 2:

#### Maintenance

At least once every six months. Increase the times of maintenance, as appropriate.